



# Magic Unit

## Instructions to set up remote viewing for events or continuous recordings on DVR


1. Highlight the connected unit right click then go to remote setup



2. Wait for the screen to come up



3. Record (tab) is where you check the continuous or event set up



4. Set to above setting
5. Apply all
6. Apply
7. OK